



INSTRUCTIONS

Flip the dockboard, A1, over onto the curbs. NOTE A2: Place the legs A3, onto the board with the bend in the legs closest to the bend in the board, EXCEPT when the board is used with refrigerated trucks, the bend in the legs is located away from the bend in the board. Install the carriage bolts A4, thru the square holes in the board and secure with the locknuts A5.

PARTS LIST

ITEM	PART NO.	NAME	MATL/SPEC
A1	per cust. order	Dockboard	
A3	per cust. order	Leg, Dock/"E" Board	
A4	8005-013 or -001	Carriage Bolt	1/2-13x1.75 lg. or 2.00 lg.
A5	8001-008	Locknut	1/2-13

Items A4 and A5 above are part of Hardware Pack #3500-H1, (8 pcs. of each)

DOCKBOARD LEG INSTALLATION

Inst. Doc. No. 8200-009
Feb 1, 1998

Revision "B"
July 10, 1998

Page 1 of 1.